

Allied BioScience

SurfaceWise®2
UNREGISTERED PRODUCT

For use by trained applicators only in accordance with the emergency exemption authorized under section 18 of the Federal Insecticide Fungicide and Rodenticide Act (FIFRA) for control of coronavirus and to reduce the spread of COVID-19 on non-porous, nonfood contact surfaces in facilities owned or controlled by Total Orthopedics Sports & Spine Clinics in Texas

**For Sale, Distribution, and Use only in the State of
Texas under FIFRA §18 Public Health Emergency
Exemption Number 20TX04,
effective 08/24/2020 through 08/24/2021**

Active Ingredient:

1-Octadecanaminium,N,N-dimethyl-N-[3-(trihydroxysilyl)propyl],chloride0.75%

Other Ingredients..... 99.25%

Total... 100.00%

Keep out of Reach of Children

Caution

FIRST AID	
If Inhaled	<ul style="list-style-type: none">• Move person to fresh air.• If person is not breathing, call 911 or ambulance, then give artificial respiration, preferably by mouth-to-mouth, if possible.• Call a Poison Control Center or doctor for treatment advice.
If in Eyes:	<ul style="list-style-type: none">• Hold eye open and rinse slowly and gently with water for 15-20 minutes.• Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye.• Call a Poison Control Center or doctor for treatment advice.
If on Skin:	<ul style="list-style-type: none">• Take off contaminated clothing.• Rinse skin immediately with plenty of water for 15-20 minutes.• Call a Poison Control Center or doctor for treatment advice.
If Swallowed	<ul style="list-style-type: none">• Call a Poison Control Center or doctor immediately for treatment advice.• Have person sip a glass of water if able to swallow.• Do not induce vomiting unless told to by a poison control center or doctor.• Do not give anything to an unconscious person.
Have the product container or label with you when calling a Poison Control Center, or doctor, or going for treatment. For emergency information concerning this product, call the National Pesticides Information Center at 1-800-858-7378, 6:30 AM to 4:30 PM Pacific time (PT), seven days a week. During other times, call the poison control center (1-800-222-1222).	

PRECAUTIONARY STATEMENTS

HAZARD TO HUMANS AND DOMESTIC ANIMALS

CAUTION: Wash thoroughly with soap and water after handling and before eating, drinking, chewing gum, using tobacco or using the toilet. Remove contaminated clothing and wash before reuse.

FOR INDOOR USE ONLY.

Environmental hazards statement for end-use products in containers greater than or equal to 5 gallons (liquid) or greater than or equal to 50 pounds (solid, dry weight)

This pesticide is toxic to fish and aquatic organisms. Do not discharge effluent containing this product into lakes, ponds, streams, estuaries, oceans or other waters unless in accordance with the requirements of a National Pollutant Discharge Elimination System (NPDES) permit and the permitting authority has been notified in writing prior to discharge. Do not discharge effluent containing this product to sewer systems without notifying the local sewage treatment authority prior to discharge. For guidance, contact your state water board or Regional Office of the EPA.

DIRECTIONS FOR USE

It is a violation of Federal law to use this product in a manner inconsistent with its labeling. Read the entire label before using. Follow all applicable directions, restrictions, protective equipment requirements, and other precautions. This labeling must be in possession of the user at the time of pesticide application. Any adverse effects resulting from the use of *SurfaceWise*^{®2} under the Public Health Emergency Exemption Number **20TX04** must immediately be reported to the Texas Department of Agriculture [Product.Registration@TexasAgriculture.gov, (512) 463-7407] and the manufacturer (Info@AlliedBioscience.com, (214) 385-4451).

Authorized Users: For sale only to Total Orthopedics Sports & Spine Clinics in Texas. Users must be trained in the application of *SurfaceWise*^{®2} by electrostatic sprayer prior to use. Only for use or application by users trained and authorized by Allied BioScience, Total Orthopedics Sports & Spine Clinics in Texas, or by users under their direct supervision. All training materials and personnel recordkeeping are available upon request by the Texas Department of Agriculture.

Product Application: Product may be used in the Total Orthopedics Sports & Spine facilities on non-food contact surfaces in non-critical areas (e.g., not for use in surgical areas or areas where invasive procedures may be performed), at the following locations:

McKinney Medical Village
7300 Eldorado Parkway, Suite 165
McKinney, TX 75070

Allen Location
1125 Raintree Circle #100
Allen, TX 75013

Product is intended to provide residual control of human coronaviruses, including SARS-CoV-2 on non-porous treated surfaces. **SurfaceWise®2** is continuously active, antiviral coating that kills 99.9% of viruses, including SARS CoV-2, within 2 hours. For continued protection **SurfaceWise®2** may be reapplied as frequently as every 7-days. This continuous protection interval may be extended upon approval by the US Environmental Protection Agency, as additional efficacy and durability data are developed. Please consult with the manufacturer to ascertain whether this has been revised. This product is intended to supplement, not replace, routine cleaning and disinfecting protocols to provide protection in between cleaning and disinfecting regimens.

Prior to application of **SurfaceWise®2**, the surface must be pre-cleaned/disinfected using a one-step EPA registered disinfecting cleaner listed under List N: Disinfectants for use against SARS-CoV-2, <https://www.epa.gov/pesticide-registration/list-n-disinfectants-use-against-sars-cov-2>. Follow all applicable label use instructions on those products.

DO NOT DILUTE SurfaceWise®2. Apply **SurfaceWise®2** immediately following pre-cleaning & disinfecting by approved List N disinfectant/cleaners, after surfaces have dried. Areas to be treated must be unoccupied by individuals other than the applicators while treatment is occurring. **SurfaceWise®2** must be applied by electrostatic sprayer, setting the flowrate to approximately 1 gallon of product/hour. Application at this rate will cover approximately 3, 200 ft²/hr Spray surfaces from a distance of 24-36 inches to the point of saturation being careful not to let the liquid start to drip. Apply to all surfaces paying particular attention to the underside of surfaces. A sheen will be present on the surface following treatment. Following application, allow treated surfaces to completely air-dry (approximately 10 minutes) prior to handling. The facilities may be reentered following drying.

To maintain protective effect on surfaces that have been treated with SurfaceWise®2: alcohol-based disinfectants and cleaners should not be used and treated surfaces should not be subjected to moisture for prolonged periods of time.

Personal Protective Equipment: Applicators must wear long pants, socks and shoes, long sleeved shirts, chemical resistant gloves, and NIOSH approved N-95 or KN-95 respirators.

Storage and Disposal: Do not contaminate water, food, or feed by storage or disposal.

Pesticide Disposal: Any unused/unopened containers of **SurfaceWise®2** must be either returned to the manufacturer or disposed of in accordance with applicable federal, state and local waste disposal regulations when no longer needed or upon the expiration of the emergency exemption, whichever is earlier.

Container Disposal: Do not reuse or refill this container. **If empty**, place in trash or offer for recycling if available. **If partly filled**, contact your local solid waste disposal agency for disposal instructions. Never place unused product down any indoor or outdoor drain. Waste resulting from the use of this product may be disposed of at an approved waste disposal site.

NOTICE OF WARRANTY AND LIMITATION OF LIABILITY

To the extent consistent with applicable law, Allied BioScience, Inc. warrants that this product conforms to the chemical description on the label thereof and is reasonably fit for purposes stated on such label only when used in accordance with directions for use under normal use conditions. It is impossible to eliminate all risks inherently associated with use of this product. Ineffectiveness or other unintended consequences may result because of such factors as the presence of other materials, or the manner of use or application, all of which are beyond the control of Allied BioScience. In no case shall Allied BioScience be liable for consequential, incidental, special, punitive, direct or indirect damages, or any other loss resulting from the use or handling of this product. All such risks shall be assumed by the Buyer. Buyer's remedy for any claim of breach of this warranty is expressly limited to return of this product and repayment of the purchase price. Allied BioScience MAKES NO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE NOR ANY OTHER EXPRESS OR IMPLIED WARRANTY EXCEPT AS STATED ABOVE.

**Manufactured by:
Allied BioScience, Inc.
7800 Dallas Parkway Suite 650
Plano, Texas 75024**